1.はじめに         お買い上げありがとうございます。ご使用の前に「取扱説明書」を よくお読みの上、正しくお使いください。         もくじ         1.はじめに       2         2.注意事項       3-5         3.付属品       6         4. 仕様       6         5. 対応急速充電規格       6         6.各部名称       7         7.使用方法       8-10         8.製品保証       11-12	と、注意事時         ・ 一、二、二、二、二、二、二、二、二、二、二、二、二、二、二、二、二、二、二、二	<ul> <li>▲ 注意</li> <li>▲ 本衆の用途以外に使用しないでください。</li> <li>▲ 本衆の用途以外に使用しないでください。</li> <li>▲ 本製品を引火性のある油、化学薬品、可燃性のものの近くで使用しないでくだ さい。</li> <li>本製品とすり、性のある油、化学薬品、可燃性のものの近くで使用しないでくだ い。</li> <li>本製品と使用するときは、USBコネクタの形状を確認し正しい向き、方向で 挿入してください。無理な挿入は故障・怪我の原因となります。</li> <li>本製品を使用するときは、USBコネクタの形状を確認し正しい向き、方向で 挿入してください。無理な挿入は故障・怪我の原因となります。</li> <li>本製品を充電中、使用中は本製品が熱くなる場合がございますので取り扱い にご注意ください。またデバイス、湖方電、本製品が満蓄電に近づくにつれ、 通常の温度に戻ります。</li> <li>PowerDelivery(PD)充電を行う際は、PD対応デバイス機器に対し、PD対応 ケーブルをご使用いただく必要がございます。</li> </ul>	<ul> <li>▲ 注意</li> <li>● 本製品を使用して接続された機器の破損・損傷・故障ねよびデータの消失に して弊社では一切の責任を負いかねます。あらかじめご了承ください。</li> <li>● 本製品を破棄する場合、各自治体の指示に従って廃棄してください。</li> <li>● 製品仕様は改善のため予告なく変更する場合があります。そのため説明書記 或の内容と異なる場合があります。そのため説明書記</li> <li>● 長時間使用しない場合は、製品寿命を保つため約3か月に1度の頻度にて充 電・放電を行ってください。</li> </ul>	●本製品       ●取扱説明書         ●本製品       ●取扱説明書            金工具       ●広仕様             型語:       ::::::::::::::::::::::::::::::::::::	6.名部名称         ① 「デジタル残量表示 (%表示・充電マーク)         ②USB-C1ポート(入出力)         ③USB-C2ポート(入出力)
2	3	4	5	6	7



20W Output Power Bank SMARTCOBY20W2C	CIO Co., Ltd. Founded in 2017 in Osaka, Japan, CIO Co., Ltd. is a manufactur-	1. Introduction         Thank you for your purchase.         Please read the "USER MANUAL" carefully before use and use it correctly.         Contents	2.Precautions         Marning       This is content that could lead to death or serious injury.         Caution       There is a possibility of serious injury or damage to property.         Marning       Marning	Caution     Do not use this product for any purpose other than its intended use.     Do not use this product near flammable oils, chemicals or flammable materials.     This product is not waterproof. Use and store in a place where it will not be exposed to liquids.	Caution     Please note that we are not responsible for any damage, damage, failure, or data loss of the equipment connected using this product.     When disposing of this product, dispose of it according to the instructions of each local government.	3. Accessories     SMARTCOBY20W2C ■User's Manual      4. Specifications  Model: SMARTCOBY20W2C	
	ing and sales company focused on dealing with the latest gadgets and smartphone accessories. With the concept of "Delivering the latest, most exciting gadgets", the company offers its products through its e-commerce site and physical stores. We always pay attention to the latest technology and continuously strive to develop products that increase the level of convenience for users. We offer high quality products in accordance with Japanese standards, but at the same time, we offer high cost performance as only an overseas manufacturer can. It is our pleasure to provide convenient gadgets to our customers.	1. Introduction       3         2. Precautions       4-6         3. Accessories       7         4. Specifications       7         5. Supported Fast Charging Protocols       7         6. Names of Each Part       8         7. How to Use       9-11         8. Warranty       12-13	<ul> <li>Stop using this product immediately if it makes any noise, generates unusual heat, has an unusual odor, or contains a foreign object.</li> <li>Do not disassemble or modify this product in any way. It may cause a fire, electric shock or injury.</li> <li>Children should not use this product alone. Do not use this product within the reach of children.</li> <li>Do not immerse the product in water or allow it to get wet.Do not touch the power plug with a wet hand. Otherwise, it may cause heat generation, fire, fire, electric shock, or explosion.</li> <li>Please do not use, leave or store the product in the frease do not use. Jeave or store the product in the frease do not use. Jeave or store the product in a high temperature environment. Do not throw this product into fire.</li> <li>Do not drop this product, place heavy objects on it, or give it a strong shock, Failure to do so may result in electric shock, malfunctions or injuries.</li> <li>Plug the power cord into a household wall outlet when using. Failure to to so may result in fire or electric shock.</li> <li>This product should be used away from heat-generating equipment.</li> </ul>	<ul> <li>When using this product, insert the shape of the USB connector in the correct orientation. Unreasonable insertion may cause malfunction or injury.</li> <li>When connecting a device to this product, be sure to follow the device's precautions and manuals to use it correctly.</li> <li>Please handle with care as this product may become hot while it is being charged or used. Also, as the device is fully charged or the product is nearing full charge, it will return to normal temperature.</li> <li>When charging with Power Delivery (PD), it is necessary to use a PD compatible device and a PD compatible cable.</li> </ul>	<ul> <li>Product specifications are subject to change without notice for improvement. Therefore, it may differ from the contents described in the manual.</li> <li>If you do not use the product for a long time, charge and discharge it about once every three months to maintain the product life.</li> </ul>	Ĭ	①Rem / Ba ②USB ③USB
	2	3	4	5	6	7	

